

TORX

XR150





08.11.2018

tandem
LAWN INDUSTRIES

TORX

XR150



		TANDEM CODE
1	Air Filter Assembly	1620-068201
2	Air Filter Cover	
3	Air Filter Base	
4	Air Filter Element	1620-030663
5	Nut, M6	
6	Stud, M6×75	1617-010306
7	Breather Hose	1620-083385
8	Gasket, Air Filter	1620-005946
9	Carburetor	1620-067501
10	Gasket, Carburetor	1620-005919
11	Insulator	1620-005596
12	Gasket, Carburetor Insulator	1620-005551
13	Stud, M6×92	
14	Clamp	
15	Fuel Hose, φ4×φ10×350	
16	Bolt, M6×14	
17	Governor Gear Bracket Assembly	1620-089077
18	Washer, φ23.5×1×φ35	
19	Crankshaft	
20	Woodruff Key	
21	Governor Gear	1620-073115
22	Washer, φ25.4×1×φ48	
23	Oil Seal, φ25×φ38×7	1620-017617
24	Pin, φ7×20	
25	Crankcase Cover	1620-068202
26	Washer, φ10×1.5×φ16	
27	Earth Bolt	1612-091103
28	Choke Linkage Lock Clamp	
29	Throttle Linkage	1620-007938
30	Idle Spring	1620-070665
31	Governor Spring	1620-074034
32	Governor Lever	1620-072937
33	Cotter Pin	
34	Oil Seal, φ8×φ14×4	1608-117631
35	Governor Gear Shaft	1620-072936
36	Dipstick	1620-004099
37	Bolt, M6×40	
38	Camshaft	1620-063525
39	Tappet	1620-004261
40	Connecting Rod Assembly	1620-050909
41	Piston	
42	Piston Pin	
43	Circlip	
44	Piston Ring Set	1620-003235
45	Intake Valve	1620-452043
46	Exhaust Valve	KIT PART OF NO. 45
47	Push Rod	1620-050914
48	Intake Valve Seal	1620-004598
49	Valve Spring	1620-004564
50	Valve Spring Seat	1620-004579

51	Rocker Arm Base	1620-004467
52	Rocker Arm Assembly	1620-004421
53	Pin, φ9×10	
54	Gasket, Valve Cover	1620-072939
55	Down Valve Cover Oil Baffle	1620-078272
56	Bolt, M5×10	
57	Upper Valve Cover Oil Baffle	1620-078273
58	Valve Cover Inner Plate	1620-068210
59	Breather Valve	1620-068205
60	Breather Plate	1620-068203
61	Screw, M3×8	
62	Gasket Valve Cover	1620-068204
63	Valve Cover Assembly	1620-068207
64	Oil Plug	1620-004172
65	Bolt, M6×22	
66	Spark Plug	
67	Muffler	1620-082652
68	Bolt, M6×14	
69	Muffler Guard	1620-081569
70	Washer, φ6	
71	Gasket, Oil Filter	1620-010256
72	Breather Cover	1620-004049
73	Crankcase	1620-067575
74	Oil Seal, φ20×φ42×7	1620-017639
75	Ignition Module	1620-087740
76	Bolt, M6×25	
77	Flywheel	1609-082150
78	Starter Cup	
79	Nut, M14×1.5	
80	Stud, M6×73	
81	Blower Housing	1620-055569
82	Stop Switch	1620-006159
83	Recoil Starter	1609-021500
84	Tape, L=150mm	
85	Screw, M6×30	
86	Cooling Fan	
87	PISTON ASSY XR150	1620-306635